



## **Attention**

Gloves must be worn when mixing Simply Gone.  
Face masks & gloves must be worn when spraying

### **Deck Preparation**

Ensure the decking area is dry and there is no rain forecast for at least **24 hours** before applying 'Simply Gone' (available from **ecodek®**).

1. Make a solution of 'Simply Gone' in a pressure spray (add last to avoid foaming) for mould and fungi: Add **10 parts water to 1 part Simply Gone**. This will be enough to cover 50m<sup>2</sup>.
2. Spray the solution over the affected area, thoroughly soaking the surface. (This is best done in the evening to avoid evaporation, try to avoid spraying during hot weather or in direct sunlight.)
3. Do **not** use the deck whilst waiting for Simply Gone to dry. The solution can take up to 5 hours to dry dependant on local weather conditions. Once it has dried it is safe to use the decking area (Please note. Simply Gone will not clear the mould on your decking overnight. It can take up to eight weeks before all of the mould has been eradicated, although you should see positive results within the first 7 – 14 days. Simply Gone will protect the deck for up to 12 months.)
4. Dispose of your Simply Gone solution or if there is any left it can be stored for up to 6 months. Please be aware that Simply Gone is biodegradable and non-accumulative in the soil. It is toxic to aquatic life and must not be disposed of in drains, water courses or in any other way that could contaminate the environment. (Please refer to the instructions on the bottle).

### **Warning**

- Keep Children and pets away from the surface until dry.
- If you get "Simply Gone" on your skin, rinse with plenty of water to dilute the solution. If unusual symptoms start to appear or the solution is swallowed, seek medical advice immediately and take the container with you.