



Balcony and Terrace System

Care and Maintenance Specification

Cleaning the Adek

- Adek should be cleaned with warm soapy water only and rinsed thoroughly with fresh clean water.
- Do **not** use steel wool, scrapers, sandpaper, scouring liquids or powders as they will permanently scratch the coated surface.
- Do **not** use strong solvents, alkaline or acid cleaners.
- Do **not** use pressure washers or steam cleaners.
- Do **not** clean the surface when it is in strong direct sunlight.

Maintaining Adek

- To prolong the life and premium appearance of your Adek installation we recommend that it is **cleaned** at least every 6 months. This frequency should be increased in exposed coastal areas or a dusty industrial environment.
- It is important to prevent the build up of dirt mould or seasonal organic matter on your Adek surface and the cleaning frequency should allow for this.
- The deck should be **inspected** every 12 months to check for defects and any changes that are of concern, including, loose boards, signs of damage, distortion, or corrosion.