

Care and maintenance guide

Cleaning Adek deck boards

Adek deck boards should be cleaned with warm soapy water only and rinsed thoroughly with fresh clean water.

- Do **not** use steel wool, scrapers, sandpaper, scouring liquids or powders as they will permanently scratch the coated surface.
- Do **not** use strong solvents, alkaline or acid cleaners.
- Do **not** use pressure washers or steam cleaners.
- Do **not** clean the surface when it is in strong direct sunlight.

Maintaining Adek deck boards

- To prolong the life and premium appearance of your Adek decking installation, we recommend that it is cleaned at least every six months.

This frequency should be increased in exposed coastal areas or a dusty or dusty industrial environments.

- It is important to prevent the build up of dirt, mould or seasonal organic matter on your Adek decking surface and the cleaning frequency should allow for this.
- The deck should be inspected every 12 months to check for defects and any changes that are of concern, including loose boards, signs of damage, distortion, or corrosion.